

Monitor Profile Installation Note: - April, 2007

Thank you for purchasing your LaCie 300/500 Series monitor,

This document explains how to install & use the generic monitor profiles available in your installation CD delivered with your LaCie 300/500 Series monitor.

A monitor profile is a file including the color characteristic information for your monitor.

Important Note: While Generic Profiles provide good results, if your work is color-critical, LaCie recommends using LaCie blue eye pro and a LaCie blue eye calibrator to create custom profiles on your monitor. LaCie blue eye pro is a full-featured hardware calibration solution designed specifically for the most demanding graphics professionals and optimized for the LaCie 300/500 Series Monitors. If you want to get the best color management out of your monitor, use LaCie blue eye pro. Refer to the LaCie blue eye pro datasheet and user manual on the LaCie website for more details.

Installing monitor profiles:

Macintosh users:

You will need to manually transfer the monitor profiles from the Monitor Profiles folder on the LaCie 300 or 500 CD to one of the following locations in Mac OS X:

Library > ColorSync > Profiles folder (to all users)

Home > User > Library > ColorSync > Profiles

To assign the profile. Use the Apple menu, select System Preferences, choose the Display Preference Icon and select the color tab. The color tab shows a scrolling list of display profiles; select the proper profile and close the Preferences panel and you are done.

PC users:

In Win 98/2000/XP and Vista

You will need to manually transfer the monitor profiles from the monitor Profiles folder on the LaCie 300 or 500 series CD to one of the following locations in C:\

Windows\System\Color folder (Win98)

WINNT\system32\spool\drivers\color folder (Win2000, WinXP, Vista)

Loading Monitor Profiles

1/ Go to your computer's desktop

2/ Right click on the desktop and select Properties

3/ Click the Settings tab

4/ Click the Advanced button

5/ Now click the Color Management tab

6/ Click Add. Select your profile from the Windows\System\Color folder (Win98) or from the WINNT\system32\spool\drivers\color folder (Win2000, WinXP, Vista). Select the profile by a double click or highlight the file and click on the Add button.

7/ Select Set as Default in the Color Management dialog box.

8/ Click OK.